



**INSTALLATION INSTRUCTIONS FOR 2000-2006
TOYOTA TUNDRA 2WD
2 1/2" SUSPENSION LIFT KIT
PART NUMBER 436 (Patent Pending)**

WARNING!!! READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE PROCEEDING. MAKE SURE THAT YOU HAVE ALL TOOLS AND PARTS BEFORE BEGINNING THE INSTALLATION.

SPECIAL TOOLS REQUIRED:
FACTORY CERTIFIED SPRING COMPRESSOR

REVTEK SUSPENSION RECOMMENDS THAT RED LOCTITE BE USED ON ALL FASTENERS UNLESS OTHERWISE NOTED. IT IS ALSO RECOMMENDED TO HAVE THE FRONT END ALIGNMENT CHECKED AFTER INSTALLATION.

KIT CONTENTS INCLUDE:

- INSTRUCTIONS INCLUDING PARTS LIST
- PRODUCT SAFETY LABEL (ORANGE)
- WINDOW DECAL
- WARRANTY

PARTS LIST INCLUDED IN KIT

<u>FRONT</u>	<u>QTY.</u>
PRELOAD SPACER - D	1
PRELOAD SPACER - P	1
TOP OUT EXTENDER	2
10MM X 1.25MM STUD	6

<u>REAR</u>	
LIFT BLOCK	2
U-BOLT	4
U-BOLT NUT	8
U-BOLT WASHER	8
EXTENSION BRACKET	1
8 X 1.25 X 16 BOLT	1
8 X 1.25 LOCK NUT	1

TORQUE SPECIFICATIONS

8MM FASTENERS	17 LBS.
10MM FASTENERS	30 LBS.
12MM FASTENERS	55 LBS.
9/16" U-BOLT	75 LBS.
LUG NUTS	75 LBS.

**PRODUCT SAFETY LABEL MUST BE INSTALLED INSIDE CAB
IN PLAIN VIEW OF ALL OCCUPANTS.**




Fig. A



Fig. B



Fig. C



Fig. D



Fig. E



Fig. F



Fig. G



Fig. H



Fig. R

FRONT OF VEHICLE

1. Park vehicle on level concrete surface.
2. Center and lock the steering wheel.
3. Block the rear wheels of the vehicle to prevent vehicle from moving in either direction.
4. Jack up the vehicle from the lift point in Figure "A."
5. Support the vehicle with jack stands from the points in Figure "A."
6. Remove the front wheels.
7. Remove the nut (14mm) and the hardware from the anti-sway bar. See Figure "B."
8. Remove the nut (19mm) and bolt (14mm) from the bottom of the strut. See Figure "C."
9. Remove the three nuts (14mm) from the top of the strut. See Figure "D."
10. Remove the strut from the vehicle.

NOTE: AT THIS TIME, IF YOU DO NOT HAVE A SUITABLE SPRING COMPRESSOR, IT IS HIGHLY ADVISED TO TAKE THE STRUT TO A QUALIFIED SERVICE CENTER.

11. Compress strut assembly and remove the nut (17mm) on the top of the strut shaft in Figure "E."
12. Release the compressor.
13. Remove the spring top plate from the strut.
14. Remove and **discard** the rubber spacer.
15. Remove (hammer) the studs from the spring top plate. See Figure "F."
16. Install (hammer) the LONGER STUDS (10MM) (provided) in the spring top plate. See Figure "G."
17. Install the PRELOAD SPACER between the spring and the spring top plate with the small diameter facing toward the spring and the Revtek Industries Logo facing out. (NOTE: The PRELOAD SPACERS are marked "P" for the passenger side and "D" for the driver side to help orient the SPACERS properly.) See Figures "H" and "R."
18. Compress the strut assembly, making sure you center the strut shaft through the spring top plate hole and that the STUDS line up with the PRELOAD SPACER reliefs. Replace nut on the top of the strut shaft and torque to spec. (Figure "E"). (Torque specs can be found on page 1.)
19. Install the TOP OUT EXTENDER over the STUDS (Figure "H").
20. Reinstall the strut by reversing the removal procedure; torque to spec. (Torque specs on page 1.)
21. When properly installed, the Revtek Industries logo should face outward. (Figure R)
22. Reinstall hardware and nut on anti-sway bar; torque to spec.
23. Replace the wheels; torque to spec.




Fig. I



Fig K



Fig. P

REAR OF VEHICLE

1. Place vehicle on level concrete surface.
2. Block front wheels to prevent vehicle from moving in either direction.
3. Make sure parking brake is off.
4. Lift the truck from the center of the rear differential housing, leaving the jack in place to support the differential.
5. Support the vehicle with jack stands from the points indicated in Figure "I."
6. Remove rear wheels.
7. Remove the proportioning valve arm where it attaches to the differential housing. Retain hardware. (Figure "K")
8. Attach the provided EXTENSION BRACKET to the differential housing using one of the original bolts (in lower position). Attach the proportioning valve arm to the EXTENSION BRACKET using the supplied BOLT (PV16B) and LOCK NUT (PVBN) for the top position and the remaining original bolt in the middle position; torque to spec. (Figure "K")
9. Remove the lower bolt on shocks to allow the differential to drop. **Do not** remove upper bolt on shocks.
10. Remove the U-bolts.
11. Carefully lower the floor jack, creating just enough room to place the LIFT BLOCK between the spring pad and the spring pack with the locating pin facing down. Make sure that the small end of taper of the BLOCK faces toward the front of the vehicle. (Figure P)
12. Raise the floor jack slightly, with just enough tension to hold the spring, BLOCK, and differential housing together.
13. Put in the new U-BOLTS, WASHERS AND NUTS supplied in the kit (Figure P); torque to spec.
14. Replace the bolt on the rear shocks.
15. Replace the wheels; torque to spec.



Limited Lifetime Warranty

Revtek Suspension products are warranted to be free from material and workmanship defects for as long as the original retail purchaser owns the vehicle upon which such products were originally installed (proof of purchase required). The consumer will be responsible for removing from the vehicle and returning any defective item, freight prepaid, and for reinstallation. This warranty is non-transferable. Revtek Suspension's limit of liability under this warranty is to repair or replace the product at Revtek Suspension's option. Consequential costs such as, but not limited to labor fees, loss of use, loss of time or freight charges are not covered. Any product that has been abused, altered incorrectly installed, or used in competition is not covered. Product finish is excluded from this warranty. Items that are subject to wear are not considered defective when worn and are not covered. The warranty is void if the "Warning to Driver" decal is not properly displayed on the vehicle. No other warranties are expressed or implied. We reserve the right to make changes in design, materials, and specifications without prior notice.

This warranty gives you specific legal rights and you may also have other rights which may vary from state to state. Some states do not allow limitations on how long an implied warranty lasts or allow the exclusion or limitation of incidental or consequential damages, the above limitation or exclusion may not apply to you.

Other than stated above, there are no warranties.

SELLER DISCLAIMS ANY IMPLIED WARRANTY OF MERCHANTABILITY

SELLER DISCLAIMS ANY IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE

This warranty to be free from material and workmanship defects shall not apply to any product which has been improperly installed modified or customized and does not apply to any components used for racing purposes or racing type activities.

To make a claim under this warranty to be free from material and workmanship defects, contact Revtek Suspension about the problem prior to removing any parts from the vehicle. If it appears that the part is warrantable, you will be given a Return Authorization (RA) number and asked to return the part freight prepaid. If the part is found to be warrantable, it will be repaired or replaced and returned to you. All freight charges are the customer's responsibility. If a replacement part is needed before the part in question can be returned, you must first purchase the replacement part. Then if the part in question is deemed warrantable, you will be credited / refunded.

Shocks and bushings are considered to be wear items. As such, they will be covered for a period of 12 months from the original installation. Any failure outside of 12 months will be considered typical wear.

REVTEK SUSPENSION, LLC 503-659-1650
15800 SE Piazza Ave #104, Clackamas OR 97015